




Flight manual for the Mikrokopter device



NIFTi

Natural Human-Robot Cooperation in
Dynamic Environments

www.nifti.eu

Josef Börding
Fraunhofer Institut für Intelligente Analyse- und
Informationssysteme – IAIS
Abteilung Adaptive Reflective Teams – ART
Schloss Birlinghoven
53754 Sankt Augustin
josef.boerding@iais.fraunhofer.de

November 2013

Index


1 Introduction

Continuous and intensive flight training is recommended for a stable navigation of a Mikrokopter. Many hours of training are needed to become a good pilot.

1.1 Mikrokopter as a flight device

Due to the round construction of the Mikrokopter the front position for a forward flight is marked by a **red propeller**.

1.2 Orientation, movement, and flight control



Left control stick

Right control stick

⇅ Lift/Descent
(Gas)

□ Rotate (Yaw)



Forward/Backward
flight (Pitch)



Left/Right flight
(Roll)

2 Preparations

2.1 Loading the battery using a Ultramat 8 charger



1. Connect the charging cable in correct polarity.
2. Connect the control cable in correct orientation. Black line = GND at Pin1.
3. Connect the charger to electric socket.
4. Set charging current to **1,5A**.
5. Start charging by pressing the **LiPo** button.

Charging is completed when the charger signals continuously loud beeps.

2.2 Loading the battery using a Ultramat 14 plus charger

2.2.1 Connect the battery



1. Connect the charging cable in correct polarity.
2. Connect the two pole cable sockets.
3. Connect the control cable in correct orientation. Black line = GND at Pin1.
4. Connect the charger to electric socket.
5. Start charging by pressing the **ENTER/START** button.

2.2.2 Charger configuration



1. Connect the charger to electric socket.
2. Use button PROG/MODE to select **LiPo manual**.
3. Push the ENTER/START button to select the charging current (selected value is blinking). Use buttons DEC or INC to adjust the charging current to **1,0 A**.
4. Push the ENTER/START button to select the charging capacity (selected value is blinking). Use buttons DEC or INC to adjust the charging capacity to **6600m A**.
5. Start charging by holding the ENTER/START button for some seconds.

2.2.3 End charging




The display prints END in the upper left corner when charging is finished. Charge current is 0 mA.

2.3 Insert battery into Mikrokopter (Mikrokopter without housing)

1. Insert the battery into the battery slot.
2. Connect the battery cables (high current cable and one balancer cable) in correct polarity.
3. Fix the battery in the battery slot by using sticky tape.
4. Fix free cables at the battery slot by using sticky tape.

The Mikrokopter is ready for flying.

2.4 Insert battery into Mikrokopter (Mikrokopter with housing)




1. Carefully insert the battery into the battery slot.
2. Connect the battery cables (high current cable and one balancer cable) in correct polarity.
3. Put free cable into the battery slot.
4. Close the battery slot by fixing the door using a knurled-head screw.

The Mikrokopter is ready for flying.


1.1 Battery exchange (hot swap) during service

A low battery may be exchanged without shutting down the UAV system. **An interruption free service is possible only if the following steps are performed in the given order.**




1

1. Verify that one balancer cable is connected to the battery balancer plug of the UAV battery.
2. Carefully pull out the battery of the UAV's battery storage slot.




3

3. Disconnect the high current plug from the UAV battery.
Now the UAV is only low level powered by the old battery. The current via the balancer plug is suitable for running the system without motor power.



4

4. Connect the free balancer cable to the new battery.
UAV now is low level powered by the new battery. The old battery will not be charged.
5. Disconnect the balancer cable from the old UAV battery.
The old battery now is completely disconnected and ready to be charged.



5

6. Connect the high current plug to the new battery.
UAV now is full powered by the new battery.
7. Carefully put new battery and cables into the battery slot.
8. Close the battery slot by fixing the door using the knurled-head screw.
9. The Mikrokopter is ready for flying again.

2.5 Mikrokopter switch on



After switching on the Mikrokopter will give a short beep for every motor. With each beep the motor will move the respective propeller.

2.6 Remote control switch on / Switch positions




The remote control is configured for use with Mikrokopter. If not, see the user's manual of the remote control.

All switches along the remote control housing 1 2 3 4 are in down positions or in positions away from the pilot.

Switch on the remote control by pushing the central ON/OFF switch.

Charge the remote control prior to use.
Do not use the remote control while charging.

2.7 Mikrokopter calibration



Make sure the Mikrokopter is standing in a horizontally leveled position (use a water level).

Make sure that the motors are switches off.

1. Move and hold the left control stick into the upper left corner (listen to three beeps) and wait, until the Mikrokopter responds with a single beep.
2. Move and hold the left control stick into the upper right corner (listen to three beeps) and wait, until the Mikrokopter responds with a single beep.

2.8 Mikrokopter start



Move and hold the left and the right control stick at the same time until all propellers of the Mikrokopter are running properly.

While starting the motors the **current GPS position will be saved** (see 3.3.4 Automatic GPS homing).

3 Fly the Mikrokopter

3.1 Emergency Stop / Shut down the Mikrokopter




First move the left control stick to the lower left corner, hold it, and then move the right control stick to the lower left corner and wait until all motors have stopped.

Never stop all motors if the Mikrokopter is flying high. It will crash to the ground immediately.

3.2 Mikrokopter manually remote control



All outside switches position are pointing „down“ (seen from the pilot) or „away from the pilot“.



Left control stick

Right control stick

⇅ Lift/Descent (Gas)

□ Rotate (Yaw)

□

Forward/Backward flight (Pitch)

□ Left/Right flight (Roll)

3.3 Semi-automatic control

Semi-automatic control makes flying the Mikrokopter easier in some aspects.

Automatic height control

Hold the Mikrokopter on the current height, when the left control stick is in its middle position.

The current height may be changed by using the left control stick.

Height accuracy depends from the air pressure. In closed rooms this is about ± 20cm, outside ± 1m, under windy conditions some meters.

Alignment independent control (care free)

In disadvantageous vision conditions it may be difficult to recognize the orientation of the Mikrokopter (where is the front).

The alignment independent control (care free) the horizontal control commands are done in relation to the pilot position, free from the current Mikrokopter orientation (yaw).

Automatic GPS position control

The Mikrokopter will automatically hold the current horizontal GPS position when the right control stick is in the neutral middle position.

Using the right control stick will change the current GPS position.

GPS accuracy depend from environment conditions and availability of GPS satellites; in closed rooms ± 50cm, outside ± 2m.

Automatic GPS homing

Precondition: automatic GPS position control is switched on.

The Mikrokopter automatically returns to the horizontal GPS position, which was stored when the Mikrokopter motors have been started.


GPS accuracy depend from environment conditions and availability of GPS satellites; in closed rooms ± 50cm, outside ± 2m.

3.3.1 Automatic height control

The Mikrokopter will automatically hold the current height. Using the right control stick will only lead to horizontal flight maneuvers (roll, pitch).



Switch **SW8** into the „up“ position (seen from the pilot)



Attention: Switch off the motors (emergency stop) after each landing and start them again.

Warning: Do not switch off the automatic height control while flying.



1. Start the Mikrokopter and hold the left control stick in the lower position.

The Mikrokopter beeps continuously in quick sequence.

2. Move the left control stick (gas) to the middle position. The beep intervals will be longer by reaching the middle position.

By reaching the middle position of the left control stick the Mikrokopter will hold the current height.

3. More gas will further lift the Mikrokopter.
4. After reaching the desired height move the left control stick to the neutral middle position. The Mikrokopter will hold the current height. Height accuracy depends from the air pressure. In closed rooms this is about ± 20cm, outside ± 1m, under windy conditions some meters.
5. Using the left control stick will change the current height.

Hint: In outside conditions the Mikrokopter should be lifted quickly.

1.1.1 Alignment independent control (care free)

In long distances and in askward light conditions it is not possible to recognize the current orientation (yaw) of the Mikrokopter. The alignment independent control (care free) frees the pilot from recognizing the Mikrokopter orientation. Control commands are relative to the current pilot position.




Switch **SW3** into the position "to the pilot".



Consequence: The Mikrokopter moves horizontally independent from its current yaw orientation. Horizontal movements will be executed in relation to the pilot position.

Attention: The pilot should not significantly chance his current position.



Left control stick

Right control stick

⇅ Lift/Descent
(Gas)

□ Rotate (Yaw)



Forward/Backward
flight (Pitch)



Left/Right flight
(Roll)

3.3.2 Automatic GPS positions control




Move switch **SW6/CTRL10/SW7** into the middle position (CTRL10).

Consequence: The Mikrokopter will automatically hold the horizontal GPS position.



Using the right control stick may modify the GPS position to hold. When the right control stick is in the middle position the current GPS position holds.

Attention: Automatic GPS positions control works properly only outside of buildings.



Left control stick

Right control stick

⇅ Lift/Descent (Gas)



Forward/Backward flight (Pitch)

□ Rotate (Yaw)

□ Left/Right flight (Roll)

3.3.3 Switch off the automatic GPS positions control



Move switch **SW6/CRTL10/SW7** into the

The automatic GPS position control is switched off.

Consequence: Mikrokopter horizontal control will be done only manually.



3.3.4 Automatic GPS homing



Move **SW6/CRTL10/SW7** into the „up“ position (SW7) schalten.

Consequence: The Mikrokopter automatically flies to the position where the motors have been started.



Hint: Automatic GPS positions control works properly only outside of buildings.

Crash warning

The return flight will be performed in a direct manner. The Mikrokopter will not avoid obstacles, but will hit them if they are located in the direct flight route.


4 Annex

4.1 System check before start-up

Perform the system inspection as shown in the following description.



**If some check does not satisfy please ask a system administrator.
Do not bring the Mikrokopter into service.**

4.1.1 Table check



Switch on the Mikrokopter.

Manually check the **cables** are reliably connected.



Check indicator lights of the FIT-PC

FIT-PC works properly: lights shine.

left: interface for laserscanner, green light

right: interface for camera, green light or blinking light


To recognize the indicator lights on the picture the cables have been disconnected.



Laserscanner check

Green and red indicator lights are shining


4.1.2 System check using a PC



Disconnet the seriell USB changer (blue) from internal FIT-PC and connect to a local PC..

Switch on the MikroKopter.

After switching on the MikroKopter will give a short beep for every motor. With each beep the motor will move the respective propeller.



Start the MikroKopter tool at the local PC.

If all checkboxes on the Status tab are green the system is ready for use.

Flight-Ctrl – Flight control

BL-Ctrl – Brushless Motor control

Navi-Ctrl – Navigation controll

Kompass – Compass

5 Quick Reference



Open the Motortest tab in the MikroKopter-Tool.

An assistant holds the MikroKopter so that the device cannot lift off, for instance by a light pressure on the laserscanner.

Be careful not to have hair or clothings coming near the propellers.


Repeat this for all 8 motors:

Gently increase the motor speed using the slider of the MikroKopter tool until max speed. Then decrease speed again to zero.

Check correct circulation direction and vibration-free movement.

After successful finalizing the tests above:

Reconnect the internal FIT-PC by using the mini USB connector.



4.2 Checkliste prior to a flight

Before starting the Mikrokopter check out the proper functioning.

Check object	Check	Status
Skids are stable and crack-free	Visual and manual inspection	
Skids are complete	Visual and manual inspection	
Distance tubes are crack free	Visual inspection for cracks	
Security ring is stable and complete	Visual and manual inspection	
All motor nacelles are fixed	Visual and manual inspection	
All motors are fixed properly	Visual inspection	
All Nylon screws are fixed	Visual and manual inspection	
All motors move free	Manual inspection	
All propellers are crack-free	Visual inspection	
All propellers move free	Manual inspection	
Cabel are stored away safely	Visual inspection	
Battery is charged	Voltage min. 16V	
Battery is mounted properly	Visual inspection	
Swich on the system		
Switch-on selftest	Visual and audible inspection	
One after another all motors will beep and turn the propeller for a short distance.		

4.3 Maintenance logbook

Wearing parts of the Mikrokopter have to be checked regularly. They have to be exchanged after a specified time of service.

All Nylon screws should be exchanged after flying the Mikrokopter for 5 hours or more (see flight log).

Date	Part label	Maintenance	Done by	Remarks
------	------------	-------------	---------	---------

4.4 Flight logbook

The flight logbook records the flying times of the Mikrokopter. Together with all the remarks it is useful for maintenance work.

Date	Start time	Flight time	Pilot(s)	Remarks
------	------------	-------------	----------	---------

4.5 Tool set and replacement equipment box

A set of tools and replacement equipment should be present in a maintenance box when flying the Mikrokopter; so light damages can be repaired immediately.

Quantity	Part
1	Slot screwdriver 5x1
1	Wrench 5,5 mm
1	Combination pliers
1	Allen wrench 2,5mm
3	Propeller turning left, grey
3	Propeller turning right, grey
1	Propeller turning left, red
1	Propeller turning right, red
1	Completely mounted motor nacelle
2	Breakaway bushing
5	Carbon distance tubes
10	Nylon screws cylinder head M3x25
10	Nylon screws countersunk head M3x25
10	Nylon screws cylinder head M3x10
10	Nylon nut M3
1	Landing device
2	Skids
1	Roll of adhesice tape
1	Reserve battery LiPo 6600, charged
1	Charging device
8	Batteries AA (Reserve for remote control)
1	WLAN antenna
10	Ready indicator red
2	Ballpen
1	Memorandum book

4.6 Wearing parts

This list of wearing parts contains parts of the Mikrokopter which have to be exchanged after some time.

Part	Specification	Order code	Vendor	Time of delivery
Nylon screws cylinder head	M3x25	527-662	rs-online.com	1 day
Nylon screws cylinder head	M3x10	484-7077	rs-online.com	1 day
Nylon screws countersunk head	M3x25	291-391	rs-online.com	1 day
Nylon nut	M3	525-701	rs-online.com	1 day
Propeller turning left	Propeller APC 12x6	074000044	hobbyking.com	14 days
Propeller turning right	Propeller APC 12x6R	074000045	hobbyking.com	14 days
Carbon distance tubes (in house manufacturing)	Carbon tube 8,8mm	7409081	r-g.de	14 days
Landing device	FlexLander XL	MK Flex Lander XL	mikrokopter.de	7 days
Skids (inhouse manufacturing)	Carbon rod	220237	conrad.de	1 day + manufacturing
Motor unit (inhouse manufacturing)	BLDC-Motor Typ 2827-35 and other parts	Roxxy2827-35	mikrokopter.de	7 days + manufacturing
LiPo Battery 6600	LiPo Akku Vislero 6600	LIPO6600_20_4 S-FLACH	mikrokopter.de	7 days+ socket exchange
Carbon element for security ring, including chuck (inhouse manufacturing)	Carbon rod Brass tube	220237 297194	conrad.de	1 day + manufacturing

4.7 Ready indicator

If the Mikrokopter is not operational a red indicator will be fixed to the device. On the indicator there are error notes.

If the Mikrokopter is operational after maintenance a green indicator will be fixed to the device. While flying the green indicator will be removed. After flying the green indicator will be fixed again, if the Mikrokopter is still in operational mode.

NIFTi Mikrokopter Operational

Operational readiness ensured by

Date

Signature

NIFTi Mikrokopter Request for maintenance

Maintenance requested by


Date

Operational readiness requested
until

Error notes:

*Please use extra sheet if necessary.
The more precise the error notes
the more helpful they are.*

5 Quick Reference



Left control stick

↕ Lift/Descent
(Gas)

↔ Rotate (Yaw)

Right control stick

↕ Forward/Backward flight
(Pitch)

↔ Left/Right flight (Roll)



n been stopped or not yet been started.
 2. Mikrokopter on a horizontally leveled surface (use a level).
 3. Move and hold the left control stick into the upper left corner (listen to three beeps) and wait, until the Mikrokopter responds with a single beep.

3. Move and hold the left control stick into the upper right corner (listen to three beeps) and wait, until the Mikrokopter responds with a single beep.

Start motors



Move and hold the left control stick until all propellers of the Mikrokopter are running properly.

While starting the motors the current GPS position will be saved.



Emergency stop

Moving the left control stick of the remote control will immediately stop all motors.

After an emergency stop the Mikrokopter has to be restarted.


Never stop all motors if the Mikrokopter is flying high. It will crash to the ground immediately.

Automatic height control

Switch **SW8** into the „up“ position (seen from the pilot)

Attention: Switch off the motors (emergency stop) after each landing and start them again.

Warning: Do not switch off the automatic height control while flying.





Alignment independent control (Care free)

Switch **SW3** into the position "to the pilot".

Consequence: The Mikrokopter moves horizontally independent from its current yaw orientation. Horizontal movements will be executed in relation to the pilot position.



Automatic GPS positions control

Move switch **SW6/CRTL10/SW7** into the middle position (CRTL10).

Consequence: The Mikrokopter will automatically hold the horizontal GPS position.



Using the right control stick may modify the GPS position to hold.
When the right control stick is in the middle position the current GPS position holds.

Attention: Automatic GPS positions control works properly only outside of buildings.



Switch off the automatic GPS positions control

Move switch **SW6/CRTL10/SW7** into the „down“ position (SW6).

The automatic GPS position control is switched off.

Consequence: Mikrokopter horizontal control will be done only manually.



Automatic GPS homing

Move **SW6/CRTL10/SW7** into the „up“ position (SW7).

Consequence: The Mikrokopter automatically flies to the position where the motors have been started.

Hint: Automatic GPS positions control works properly only outside of buildings.



Crash warning

The return flight will be performed in a direct manner. The Mikrokopter will not avoid obstacles but will hit them if they are located in the direct flight route.